



Firmware Warnung!

Bitte achten Sie darauf, dass Sie die richtige Firmware auf dem Gerät installieren! Bitte vergleichen Sie die Modell-Nummer, die auf Ihrem Gerät gedruckt ist mit dem Dateinamen des Firmware-Updates!

Bitte beachten Sie, dass Firmware-Updates nur empfohlen sind, wenn Sie technische Probleme mit Ihrem Gerät feststellen. Firmware-Updates beinhalten ein gewisses Maß an Gefahr. Die Firmware-Updates sind mit Vorsicht durchzuführen. Zur Vermeidung von Schäden oder Fehlfunktionen bei der Aktualisierung vermeiden Sie bitte Stromausfall oder Störungen am Gerät.



Firmware warning!

Please make sure to install the matching firmware on your device! Please compare the model number that is printed on your device and the filename of the firmware update!

Please note that firmware updates are only recommended when experiencing technical problems with your device. Firmware updates include a certain level of dangers. The firmware updates have to be done with caution. To prevent damage or malfunction during the update process, your system must run without power loss or interference.



Firmware Updates einspielen

Die Firmware ist das Betriebssystem (OS), welches auf dem Player installiert ist.

Firmware Updates können neue Funktionen, Verbesserungen und Fehlerkorrekturen enthalten

Um zu ermitteln, welche Firmwareversion auf dem Player installiert ist

1. Wählen Sie System und System Info im Setup Menü.
2. Die Firmware Version wird unter „Software“ angezeigt.
3. Vergleichen Sie die Nummer mit der neuesten Version.

Laden Sie die neueste Version von unserer Webseite, falls diese noch nicht installiert ist.

Schritt 1: Vorbereiten des USB Sticks

Sie benötigen einen USB Stick zum einspielen des Updates. Kopieren Sie die „install.img“ Datei des Updates in das Wurzelverzeichnis ihres USB-Sticks.

Schritt 2: Verbinden des USB Sticks

Stecken Sie den USB Stick in eine der beiden USB Host Buchsen des Players.

Schritt 3: Drücken Sie den Standby-Schalter

Drücken Sie den Standby-Schalter an der Frontblende des Gerätes und halten Sie diesen gedrückt.

Schritt 4: Einstecken des Netzteils

Stecken Sie den Stecker des Netzteils in die DC Eingangsbuchse. Warten Sie mindestens 20 Sekunden und lassen Sie dann den Standby-Schalter wieder los.

Die Installation der Firmware wird nach 30 Sekunden gestartet. Die LED an der Frontblende wird aufleuchten und während der Installation blinken. Wenn das Gerät mit einem Fernseher verbunden ist, wird der Installationsstatus angezeigt.

Bitte warten Sie etwa 2 Minuten. Die Installation wird dann abgeschlossen sein, die LED geht aus und der Player wird automatisch neu gestartet.

Hinweis:

Schalten Sie das Gerät nicht während der Installation ab und entfernen Sie den USB Stick nicht aus dem Gerät. Der Player könnte dadurch irreparabel beschädigt werden.

Upgrading the Firmware

The firmware is the operating system (OS) installed on the device. Firmware upgrades can bring new features, improvements and bug fixes.

To check whether you have the latest version of firmware:

1. Select System and System Info the Setup menu.
2. The firmware version number is displayed behind “Software”.
3. Compare it with the latest firmware released.

Download the latest firmware from our official website.

Step 1: Prepare the USB Pen Drive

You will need a USB Pen Drive for firmware upgrade. Copy the “install.img” file for upgrade to the root directory of your USB Pen Drive.

Step 2: Connect the USB Pen Drive

Plug the USB Pen Drive into one of the USB HOST ports of the player.

Step 3: Hold the POWER / STANDBY button

Press and hold the **POWER / STANDBY** button on the front panel, and do not loosen.

Step 4: Connect the power cable

Plug the power cable into the DC IN jack, wait for about 20 seconds or more, and then loosen your finger on the **POWER / STANDBY** button.

Firmware installation will start in about 30 seconds. The LED indicator on the front panel will be enlightened and flashing during installation. If it is connected to a TV set, a blue install page will appear on the TV screen.

Please wait for about 2 minutes, the installation will be completed, the LED indicator will go off and the player will be reboot automatically.

Note:

Do not turn off the power during installation.

The USB Pen Drive is not allowed to be unplugged during installation.